


E41 KEYLESS



1	Z41CDXSM	E41 Top -shell right, black
1	Z41CSXSM	E41 Top-shell left, black
2	Z41FNM	E41 bottom shell, black
3	Z599	Nylon stop bag opening yarn
4	Z106	Bolt
5	Z109	Long bolt springs
6	Z112R	Red pulley, 4 pcs.
7	Z140R	Key locks with corresponding bush with red handle
8	Z1237	Push button spring with washer
9	Z195	Pin D. 04x80 mm
10	Z217	Push button
11	Z236	Hinge spring
12	Z277	Plate below lock
13	Z285	Inner strap
14	Z312	Hinge plate

15	Z314N	Hinge black
16	Z405 ▲	Name holder
17	Z1235	Injection covering cap
18	Z548	Keyless logo
19	Z590R	Pin. Medium, 2 pcs.
20	Z726	Black lock lining
21	Z533	Reflectors with white bottom (couple/x2)
22	Z148M	Mounted hinge (including combination)
23	Z200	GIVI logo Monokey®
24	Z539	Red hooks to fix lid, (1 pcs.)
25	Z544	Caps (4 pcs.§)
26	Z545	Keyless round medal chromed
27	Z592	41 mm pin to fix the lid
28	Z1239	Hinge plate in nylon
29	Z1238	Nylon tooth catch mechanism